



Príklady výpočtu pre rám London +
 $v = d - 54 = 1000 - 54 = 946 \text{ mm}$

$d = 1000 \text{ mm}$ (šírka krídla)	2 dvere $D = 2000 \text{ mm}$ $d = (D+Z)/N = (2000+27,5) / 2 = 1014 \text{ mm}$
	3 dvere $D = 2000 \text{ mm}$ $d = (D+2Z)/N = (2000+2*27,5) / 3 = 685 \text{ mm}$
	4 dvere $D = 3000 \text{ mm}$ $d = (D+3Z)/N = (3000+3*27,5) / 4 = 770,6 \text{ mm}$
	4 dvere $D = 3000 \text{ mm}$ $d = (D/2 + Z) / 2 = (3000/2 + 27,5) / 2 = 764 \text{ mm}$
	5 dverí $D = 4000 \text{ mm}$ $d = (D+4Z)/5 = (4000+4*27,5) / 5 = 822 \text{ mm}$
	6 dverí $D = 5000 \text{ mm}$ $d = (D+5Z)/6 = (5000+5*27,5) / 6 = 856,3 \text{ mm}$
	$h = 2750 \text{ mm}$ (výška krídla)